

Tips for Air Travel with an F35 Power Assist



1. Check Airline Information Early

Research the airlines' policies regarding mobility Power Assist before booking your ticket. Confirm if your airline will take your F35 on board and if there is any additional information they'll require.

2. Read Your Manufacturers Information

Check the manufacturers website and owners manual for any specific guidelines for safe transit.

3. Read Guidelines From Trusted Organisations

The CAA, IATA and other organisations provide guides for travelling with mobility products.

4. Consider Additional Insurance For Your F35

Airlines are responsible for damage during transit, but the reimbursement might not cover the cost of your F35. Check if your F35 is covered by your home or travel insurance, or consider a separate policy.

5. Prepare Your F35 For Travel

Ensure that your F35 and all components are well maintained and you have everything you need to use your F35 abroad.

6. Request Special Assistance And Provide Information To The Airline

Provide battery and IATA information when booking your ticket. Arrive at the airport early and discuss your timings with airport assistance services. Discuss how you can continue to use your F35 until you board.

7. Have Information About Your F35'S Battery Easily Accessible

Keep an owners manual with battery information and relevant travel certification with you at all times.

8. Make Sure Your Fuse Is Kept Safe

With the easy to remove fuse port the battery stays contained in the F35 and is isolated. Ensure the fuse is kept safe as this will need to be reinserted upon arrival. You might also consider buying a spare fuse.

9. Review The Condition Of Your F35 Upon Arrival

Check for any damage to your F35 and record or photograph if found and make a claim if necessary.